

Where is the Visage Wi-Fi Coverage Area?

If conditions allow, the Visage Wi-Fi network covers the car storage and staging areas.

Does the VDU need to be powered on to connect to the network? Yes.

Which updates or features require the car to be in the Wi-Fi coverage area?

- Publishing Advertisements
- Creating or Modifying Action Zones
- Use of Vehicle Staging & Lockdown Modes
- Configuring Pace of Play Options
- Car History & Vehicle Faults
- Software Updates & Enhancements